

S.NO.	PART CODE	DESCRIPTION	Quantity/ Tractor
1	D10264200	PTO SPRING	1
2	D10262150	PTO BALL	1
3	D10436640	COUPLING PROPELLER SHAFT REAR (4WD)	2
4	D10782520	GASKET FRONT GUARD PROPELLER SHAFT	1
5	D10548780	GASKET REAR GUARD PROPELLER SHAFT	1
6	D10720380	HOSE RADIATOR UPPER	1
7	D10720370	HOSE RADIATOR LOWER TO WATER PUMP	1
8	D10914890	HOSE AIR CLEANER	1
9	D10898960	HOSE PIPE AIRCLEANER TO TURBOCHARGER	1
10	D10244880	AIR CLEANER ASSEMBLY	1
11	D10307780	RESTRICATOR INDICATOR	1
12	D10797680	HOSE ENGINE AIR INTAKE	1
13	D10898430	HOSE TURBOCHARGER OUTLET TO PIPE TURBOCHAGER	1
14	D10898440	HOSE PIPE TURBOCHARGER TO PIPE EXTENSION	1
15	D10559730	GASKET PIPE TAIL ASSEMBLY EXHAUST MUFFLER	1
16	D10621640	GASKET EXHAUST ELBOW	1
17	D10541000	GASKET FUEL TANK NECK	1
18	D10761840	HOSE ASSEMBLY FUEL TANK TO PROTECT FILTER	1
19	D10761850	HOSE ASSEMBLY PROTECT FILTER TO FUEL FILTER	1
20	D10496220	HOSE ASSEMBLY WATER SEPARATOR TO FEED PUMP	1
21	D10761880	HOSE ASSEMBLY FUEL TANK RETURN	1
22	D10329510	CLAMP HOSE WORM DRIVE 20MM	2
23	D10684690	CLAMP SPRING WIRE HOSE FOR DIA 6.8	1
24	D10633790	HOSE CRDI PRESSURE LIMITING VALVE BACKFLOW	1
25	D10757260	HOSE POWER STEERING SUCTION OUTLET	1

S.NO.	PART CODE	DESCRIPTION	Quantity/ Tractor
26	D10519950	HOSE STEERING SUCTION TUBE	1
27	D93600090	SEAL O RING 0.103X0.625	1
28	D93600580	SEAL O RING 1.78X23.52	1
29	D93600670	SEAL O RING 1.78X15.6	1
30	D10174950	SEAL BANJO BOLT DISTRIBUTOR TO CYLINDER TUBE	15
32	D10756750	HOSE HYDRAULIC SUCTION TUBE	1
33	D10124600	HOSE HYDRAULIC LIFT OIL	1
34	D10729020	HOSE HYDRAULIC SUCTION	1
35	D93600020	SEAL O RING 0.139"X1.250"	2
36	D93600580	SEAL O RING 1.78x23.52	1
37	D93600080	SEAL O RING 0.139"x1.125"	1
38	D10174960	BOLT BANJO M18x1.50	7
39	D10703660	BOLT BANJO M16 X 1.5 X 55	1
40	D10723160	BUSH IGUS THROTTLE ROD	1
41	D10676640	CABLE ASSEMBLY FOOT THROTTLE	1
42	D10770870	CABLE ASSEMBLY HAND THROTTLE	1
43	D10881720	CABLE ASSEMBLY CLUTCH PEDAL	1
44	D10558920	GUIDE SUPPORT LEVER (IGUS)	1
45	D10639170	CABLE ASSEMBLY HOLD PANEL HOOD TOP	1
46	D10770760	STRUT BONNET OPENING	1
47	D10889580	CABLE EMERGENCY LATCH ASSEMBLY HOOD	1
48	D10561340	MIRROR AND ROD ASSEMBLY REAR VIEW LH	1
49	D10561350	MIRROR AND ROD ASSEMBLY REAR VIEW RH	1
50	D10896860	KEY IGNITION LOCK	1
51	D10645940	BUZZER ASSEMBLY	1

Laguna Niguel, California 92677

www.FarmTracUS.com
www.CanteenMWF.com
www.DHKI.com
www.ULiveToday.com



Phone: (949) 332-0755
(310) 728-6171
info@farmtracus.com
kamk@dhki.com

S.NO.	PART CODE	DESCRIPTION	Quantity /Tractor
52	D10757990	FLASHER ASSEMBLY (LED)	1
53	D10630600	SWITCH ASSEMBLY HAZARD	1
54	D10630550	SWITCH ASSEMBLY BEACON LAMP	1
55	D10533070	SWITCH ASSEMBLY COMBINATION	1
56	D10027010	GROMMET COMBINATION SWITCH	2
57	D10028020	HORN AND BRACKET ASSEMBLY	1
58	D10794060	SWITCH ASSEMBLY HEATER & STARTER	1
59	D10522130	SWITCH ASSEMBLY ECO MODE (NO TYPE)	1
60	D10498400	SWITCH ASSEMBLY STOP LAMP	1
61	D10522130	SWITCH ASSEMBLY ECO MODE (NO TYPE)	1
62	D10498400	SWITCH ASSEMBLY STOP LAMP	3
63	D10501470	PLOUGH LAMP ASSEMBLY	1
64	D10497580	7 PIN TRAILER SOCKET (FOR USA)	1
65	D10135490	SOCKET ASSEMBLY TRAILER ELECTRICAL	1
66	D10590410	SOCKET MOBILE CHARGER	1
67	D10758610	HARNESS ASSEMBLY ELECTRICAL MAIN	1
68	D10758620	Wiring Harness IP	1
69	D10758630	Wiring Harness Fender LH	1
70	D10758640	Wiring Harness Fender RH	1
71	D10401250	HARNESS ASSEMBLY GLOW PLUG	1
72	D10758580	HARNESS ASSEMBLY PROJECTOR LAMP	1
73	D10510390	HARNESS FOR BEACON LAMP	1
74	D10681540	HARNESS ASSEMBLY AIR RESTRICTION SENSOR	1
75	D10780590	HARNESS ASSEMBLY PIGTAIL ENGINE (TEMPERATURE SENSOR)	1



76	D10569030	CABLE ASSY BATTERY TO ISOLATOR	1
----	-----------	--------------------------------	---

S.NO.	PART CODE	DESCRIPTION	Quantity /Tractor
77	D10657260	CABLE ASSY ISOLATOR TO START AR SOLENOID	1
78	D10723660	CABLE ASSEMBLY BATTERY TO GROUND	1
79	D10762070	GROMMET STEERING COLUMN ASSEMBLY	1
80	D10013800	GASKET HYDRAULIC PUMP	1
81	D10012900	SEAL POWER STEERING PUMP	1
82	D10104180	PUMP ASSEMBLY HYDRAULIC LIFT OIL (TANDEM)	1
83	D10257560	SENSOR UNIT BOOST PRESSURE	1
84	D10324730	GASKET COVER CYLINDER HEAD	1
85	D10257460	ELECTRONIC CONTROL UNIT FUEL INJECTION	1
86	D10257580	SENSOR UNIT CRANK SPEED	1
87	D10257570	SENSOR UNIT CAM PHASE	1
88	D10257550	SENSOR UNIT WATER TEMPERATURE	1
89	D10257560	SENSOR UNIT BOOST PRESSURE	1
90	D10328100	ELECTRONIC THROTTLE CONTROL (E4.312TCI)	1
91	D10253700	GASKET EXHAUST MANIFOLD (PORT 4th)	3
92	D10287100	GLOW PLUG ENGINE	1
93	D10702050	HOSE OIL MIST SEPARATOR DRAIN UPPER E3.276 CRDI	1
94	D10702060	HOSE OIL MIST SEPARATOR AIR OUTLET E3.276 CRDI	1
95	D10702070	HOSE OIL MIST SEPARATOR OIL DRAIN LOWER E3.276 CRDI	1
96	D10679930	HOSE ASSEMBLY WATER EGR COOLER OUTLET	1
100	D10679940	HOSE ASSEMBLY WATER EGR COOLER INLET	1
104	D10704520	HOSE AIR COMPRESSOR DRAIN UPPER (E3.276 CRDI)	1
105	D10739120	BELT POLY V GROOVE (E3.276 CRDI)	1





106	D10911090	BELT POLY V GROOVE AC COMPRESSOR (LEN	1
107	D10679760	GASKET AIR COMPRESSOR (E4.346TCI)	1

S.NO.	PART CODE	DESCRIPTION	Quantity /Tractor
108	D10971790	HOSE OIL MIST SEPARATOR OIL DRAIN LOWER E3.276 CRDI	1
109	D10244890	ELEMENT PRIMARY FILTER AIR CLEANER (DRY TYPE)	1
110	D10244920	ELEMENT SECONDARY FILTER AIR CLEANER (DRY TYPE)	1
111	D10297570	STRAINER ASSEMBLY HYDRAULIC OIL	1
112	D10594210	FILTER ASSEMBLY HYDRAULIC LIFT OIL	1
113	D10614700	FILTER ASSEMBLY FUEL	1
114	D10293210	FILTER ASSEMBLY FUEL WITH WATER SEPARATOR	1

